

- Pull out the cartridge and clean the contacts of the printhead with a damp cloth.
- Try to make an imprint again.
- If it won't work, pull out the cartridge again and...
- Clean the contacts inside the e-mark carefully with a damp cloth.
- If it still does not work, use a new printhead or contact your point of sale.

